




WINTER IN ARENDELLE




5+
2564

Includes:





AA/LR6 x3 Batteries Not included
Requires 3 x 1.5V AA/LR6 batteries

Create Your Dream Scene:



WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

FOR BEST ILLUMINATION, USE IN A DARKENED ROOM.



KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE — DO NOT DISCARD

Questions? Visit unclemilton.com

Uncle Milton

MANUFACTURED BY
UNCLE MILTON INDUSTRIES, INC.
P.O. Box 6281
THOUSAND OAKS, CA 91359 USA
©2015 UMI. All rights reserved. ® and TM designate
trademarks of Uncle Milton Industries, Inc.
MADE IN CHINA

BATTERY SAFETY INFORMATION

- Only adults should install and replace batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not dispose of batteries in fire. Battery may explode or leak.
- Batteries should be recycled or disposed of as per state and local guidelines.



This product and its batteries must be disposed of separately at your local waste recycling centre. Do not dispose them in your household waste bin.