

AA/LR6

x4

Batteries are not included.
Requires 4 AA / LR6 batteries.

5+

16154




CRITTER CATCHER BUG VAC™


ACTIVITY GUIDE
WITH INSTRUCTIONS

Always use extreme care when collecting and observing live creatures.

Place the nose cone over a bug and press the vacuum button.



Once the bug is inside the observation chamber, remove the observation chamber and immediately flip the magnifier cap closed.



Don't forget to release the bug back into the wild.



CAUTION:

Do not look directly at the sun.
Do not leave in direct sunlight due to the risk of fire from magnifying glasses.

My Fellow Explorer,

Collecting bugs and other insects in the field can be extremely challenging, and getting up close to observe them can be even more so.

The Critter Catcher Bug Vac tackles both of these problems. The powerful suction makes collecting all kinds of critters easy and fun. The removable viewing chamber comes with a built-in magnifier, so you can see what you collected up close, in great detail.

Don't forget, as fun as it is to collect and observe insects, it's important to return them to their natural environment when you are done observing them!

Start exploring with the activities described below, or use your imagination to think of your very own games and adventures!

Beat The Clock

Give yourself 20 minutes to go on a mission to find, collect, and observe as many bugs as possible. How many critters did you collect? How many different kinds? Be sure to release the bugs safely back into their habitats after observing them.

Play against yourself to see if you can beat your record, or play against a friend.

Bug Master

Did you know that there are more than 900,000 named bugs and insects in the world? Most of them are very important to the balance of nature.

As you go on your critter-collecting journeys, keep a log of everything you find. Then, find a good insect-identification website or book, and learn more about your discoveries!




JOIN THE ACADEMY
NatGeoAcademy.com

Battery Installation


Requires a small Phillips-head screwdriver.

1. Using a Phillips-head screwdriver, loosen the screw in the battery cover, and remove the battery cover as shown.



2. Insert four AA/LR6 batteries (not included) as indicated in the battery compartment.

3. Replace battery cover and retighten screw.



Before you go searching for bugs, make sure the observation chamber is securely connected.



National Geographic's net proceeds support vital exploration, conservation, research, and education programs.

BATTERY SAFETY INFORMATION

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not dispose of batteries in fire. Batteries may explode or leak.

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE — DO NOT DISCARD

Questions? Visit unclemilton.com

**Uncle
Milton®**

MANUFACTURED BY
UNCLE MILTON INDUSTRIES, INC.
P.O. Box 6281
THOUSAND OAKS, CA 91359, U.S.A.
©2012 UMI. All rights reserved. ®
and TM designate trademarks of
Uncle Milton Industries, Inc.
PRINTED IN CHINA

 **NATIONAL
GEOGRAPHIC™**

Parents: Experience the National Geographic Channel.
Call your cable or satellite provider for availability.

Visit our website: kids.nationalgeographic.com
© 2012 National Geographic Society
NATIONAL GEOGRAPHIC and Yellow Border Design
are trademarks of National Geographic Society.
All rights reserved.