

AA/LR6

x2

Batteries are not included.  
Requires 2 AA / LR6 batteries.

5+

16148



# EXPLORER'S TORCH™

## ACTIVITY GUIDE WITH INSTRUCTIONS



### WARNING:

CHOKING HAZARD - Small parts.  
Not for children under 3 years.  
Adult assembly required.



# My Fellow Explorer,

Not too long ago, explorers who ventured into caves and searched dark places carried torches, which burned brightly, so they could see where they were going and what they were

doing. Your Explorer's Torch will also help you illuminate your adventures, with authentic details like a brilliant, realistic flickering flame.





Start exploring with the activities described below, or use your imagination to think of your very own games and adventures!

## Hidden Creature Search

As nighttime falls, explore your backyard using your Explorer's Torch, and look for nocturnal creatures that may be hiding in the bark of trees or under rocks. Some critters are drawn to the light, while others may scurry away from it. Always explore with an adult close by.



# Closet Caves And House Hideouts

Here is a fun way you can pretend you are exploring a dark and mysterious cave right in your own room! Walk into


your closet or another house hideout with your Explorer's Torch unlit, and illuminate the Torch while inside.

Explore things from top to bottom; you'll be surprised how different things look with only the flickering light of your torch. What do you see?



JOIN THE ACADEMY  
[NatGeoAcademy.com](http://NatGeoAcademy.com)





### Installing Batteries

1. Gently press down on the flame and turn counter-clockwise to detach the flame from the handle.
2. Insert two AA/LR6 batteries (not included) as shown.
3. Reconnect the flame to the handle and turn clockwise to lock the flame in place.


To turn on:  
Twist the flame clockwise

To turn off: Twist the flame counterclockwise

### Hanging the Torch

The torch hanger is only intended to be mounted on a vertical wall.

Locate a stud in the wall or use the wall-mounting hardware included to mount the torch hanger on the wall as shown.







National Geographic's net proceeds support vital exploration, conservation, research, and education programs.

#### BATTERY SAFETY INFORMATION

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not dispose of batteries in fire. Batteries may explode or leak.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE — DO NOT DISCARD**

Questions? Visit [unclemilton.com](http://unclemilton.com)

**Uncle  
Milton**®

MANUFACTURED BY  
UNCLE MILTON INDUSTRIES, INC.  
P.O. Box 6281  
THOUSAND OAKS, CA 91359, U.S.A.  
©2012 UMI. All rights reserved. ®  
and TM designate trademarks of  
Uncle Milton Industries, Inc.  
PRINTED IN CHINA

 **NATIONAL  
GEOGRAPHIC™**

Parents: Experience the National Geographic Channel.  
Call your cable or satellite provider for availability.

Visit our website: [kids.nationalgeographic.com](http://kids.nationalgeographic.com)  
© 2012 National Geographic Society  
NATIONAL GEOGRAPHIC and Yellow Border Design  
are trademarks of National Geographic Society.  
All rights reserved.

16148-0250-0512-V02