

AA/LR6

x4

Batteries are not included.  
Requires 4 AA / LR6 batteries.

5+  
16150



# STARRY NIGHT LANTERN™

**ACTIVITY GUIDE**  
WITH INSTRUCTIONS

# My Fellow Explorer,

Whether you're on a camping trip or taking a nighttime walk, it's important to have a bright light source close at hand. Your Starry Night Lantern can illuminate a wide area around you anywhere you go, but it also has a special feature not found in other explorer's lanterns: it can project a glowing field of stars on the inside of your tent or on the ceiling of your room!

Start exploring with the activities described below, or use your imagination to think of your very own games and adventures!

## The Great Outdoors


Nothing says exploring more than being in the great outdoors! Around dusk, grab your lantern and head outside. Find a spot to stargaze and look for constellations in the night sky. After your search, turn on your lantern and make your way back inside to draw constellation pictures.

# The Great Indoors

Set up some blankets on the floor in your bedroom. If you have a small tent and your parents' permission, set up the tent inside your room for some added fun! Invite some friends over, grab some tasty snacks, and pretend you are camping out. Turn off the lights, maybe tell a spooky story or two, and have your Starry Night Lantern nearby to shine a bright light! Want to see the stars? Switch on the Star Field and gaze into the night sky—in your own room!




JOIN THE ACADEMY  
[NatGeoAcademy.com](http://NatGeoAcademy.com)



### Battery Installation

Requires a small Phillips-head screwdriver.

1. Using a Phillips-head screwdriver, loosen the screw in the battery cover, and remove the battery cover as shown.
2. Insert four AA/LR6 batteries (not included) as indicated in the battery compartment.
3. Replace battery cover and retighten screw.





National Geographic's net proceeds support vital exploration, conservation, research, and education programs.

#### BATTERY SAFETY INFORMATION

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not dispose of batteries in fire. Batteries may explode or leak.

**KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE — DO NOT DISCARD**

Questions? Visit [unclemilton.com](http://unclemilton.com)

**Uncle  
Milton**®

MANUFACTURED BY  
UNCLE MILTON INDUSTRIES, INC.  
P.O. Box 6281  
THOUSAND OAKS, CA 91359, U.S.A.  
©2012 UMI. All rights reserved. ®  
and TM designate trademarks of  
Uncle Milton Industries, Inc.  
PRINTED IN CHINA

 **NATIONAL  
GEOGRAPHIC™**

Parents: Experience the National Geographic Channel.  
Call your cable or satellite provider for availability.

Visit our website: [kids.nationalgeographic.com](http://kids.nationalgeographic.com)  
© 2012 National Geographic Society  
NATIONAL GEOGRAPHIC and Yellow Border Design  
are trademarks of National Geographic Society.  
All rights reserved.

16150-0250-0512-V02