

RC Rat

6+
2140


AAA/LR03 x3 Batteries not included
Requires 3x 1.5V AAA/LR03 batteries

AA/LR6 x2 Batteries not included
Requires 2 x 1.5V AA/LR6 batteries

Installing batteries into rat


Tool required - Small Phillips head screwdriver

1. Using a Phillips head screwdriver remove the battery cover from the bottom (See Fig. 1).
2. Insert 3 "AAA" batteries as indicated in the battery compartment, and replace cover.



Install batteries into controller

1. Using a Phillips head screwdriver remove the battery cover from the back of the controller (See Fig. 2).
2. Insert 2 "AA" batteries as indicated in the battery compartment, and replace cover.



BATTERY SAFETY INFORMATION

- DO NOT USE rechargeable batteries;
- Do not mix new and old batteries, batteries of different types, alkaline and standard (carbon-zinc);
- Do not charge non-chargeable batteries;
- Use only batteries of the same or equivalent as recommended;
- Insert batteries as indicated inside the battery compartment;
- Remove batteries during long periods of non-use;
- Never short-circuit the battery terminals;
- Always remove exhausted batteries from product. Dispose of batteries safely; Do not dispose of this product in a fire. The batteries inside may explode or leak.

Using your RC Rat

1. Turn the power switches to the "ON" position on both the controller and rat (See Fig. 1 and Fig. 2).
2. Move the rat forward or make it turn using the buttons on the controller (See Fig. 3).




Fig. 3

Note: For best performance use on a smooth flat surface like a hardwood floor.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna;
- Increase the separation between the equipment and receiver;
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected;
- Consult the manufacturer or an experienced radio/TV technician for help.

FCC ID: XCY2027UMI2010
MADE IN CHINA

27 Mhz

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions.

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE - DO NOT DISCARD

Questions? Visit unclemilton.com

Uncle Milton

MANUFACTURED BY UNCLE MILTON INDUSTRIES, INC.
P.O. Box 6281 THOUSAND OAKS, CA 91359 USA
©2011 Uncle Milton Industries, Inc., all rights reserved.
® and TM designate trademarks of Uncle Milton Industries, Inc.
PRINTED IN CHINA

2140-0250-0411-V02